



INSTALLATION INSTRUCTIONS

3" BULL BAR PART #82001.09&82501.09

Bull Bar

1994-2001 Dodge Ram

Total Units	Part Description	Total Units	Part Description
1 set	Bull Bar	8 pieces	M12*30 Hex Bolt
10 pieces	M12 Hex Nut	1 set	Mounting Bracket
10 pieces	12mm Flat washer	2 pieces	M12*100 Hex Bolt
10 pieces	12mm spring washer		

INSTALLATION PROCEDURE:

Step 1. Remove the contents from box and check for damage verify all parts are present. Read Instructions completely before beginning.

Step 2. Note: It may be necessary to remove/relocate front license plate and license plate bracket. It is not required but strongly recommended. If local /state laws requires a license plate, License plate relocation.

Step 3: From underside vehicle, locate tow holes in frame between body mount flanges. If bolts are present Remove and save for Reinstallation. Note: On some models, Hex Nuts need to be removed from inside frame rail. A long extension and swivel may be required

Step 4: Determine which holes in bracket are used for your vehicle. Install bolts from inside frame rail pointing tow outside of vehicle. Attach brackets to body mounts as shown

Step 5: Remove lower air dam from vehicle. Create centerline by measuring 17 1/2" from centerline and making a parallel from this line. Measure 1 3/8" from bottom of air dam. Note: Additional trimming and alignment of air dam may be necessary. See Figure 3.

Step 6: Attach Bull Bar to Brackets using 1/2" Fasteners. Leave Loose.

Step 7: Level and adjust Bull Bar as Desired. Torque 1/2" Fasteners to 65 FT. LB and Existing Fasteners (If used) to 61Ft. LBS.

